


FIG. 1



• E

1 • 6 •

• C

2 • 7 •

3 • 8 •

4 • 9 •

5 • 0 •




FIG. 1b

FIG. 1c





FIG. 1d



Q III.d







FIG. 3






FIG. 3d

FIG. 4





FIG. 5






FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15

R. = Reader Unit




FIG. 16




FIG. 17




FIG. 18




FIG. 19




FIG. 19a





FIG. 20

FIG. 21






FIG. 22




FIG. 23




FIG. 24




FIG. 25




FIG. 25a




FIG. 25b

Encoder Buttons: 0 - 9, numerical entries,
 En, initial reset and data entry into processor
 U, upper case for numbers with meaning as given below
 if pushed twice, (double upper case), see other meanings.
 I, II, III, IV. stores for bank issued credit amounts
 α , β , γ = stores for summed-up discounts data,
 for three by customer chosen selling houses.
 double arrow button: for moving cursor forward/backward.

Single Upper Case
combined with:

1...AirTravel
 2...Other Travel
 3...Banking (Updates only)
 4...Health and Household
 5...Restaurants
 6...Groceries etc.
 7...Stationaries
 8...Business
 9...Display expenditure only
 irrespective of category

Double Upper Case
combined with:

1...total air travel since update
 2...total other travel since update
 3...date of last update (for I - IV resp.)
 4...total expenditure on HH since update
 5...total on restaurants since update
 6...total on groceries since update
 7...total on stationaries since update
 8...total on business items since update
 9...display of cash in money store

For the following, the PIN must be entered afresh just prior to the codes:

Single Upper Case
combined with:

9+I ...display of residual credit in Credit Store I
 9+II ...display of residual credit in Credit Store II
 9+III...display of residual credit in Credit Store III
 9+IV...display of residual credit in Credit Store IV

9+ α ...display of accumulated discounts derived from purchases in Discount Shops
 (normally, it is expected that customers will select no more than three shopping
 sources offering recovery of discounts either for additional purchases
 or as cash).

9+ β as above
 9+ γ as above

Double Upper Case
combined with:

Ø ...Cancel the preceding data entry
 En...Display instant time and date (correction of time and date can only
 be obtained from a clock terminal).

TABLE I

FIG. 26




FIG. 27

